

Panasonic

16-Channel VoIP Gateway Card Programming Guide

Model No. **KX-TDA0490**



Thank you for purchasing a Panasonic 16-Channel VoIP Gateway Card.
Please read this manual carefully before using this product and save this manual for future use.

Table of Contents

1	IP-GW16 Maintenance Utility	3
1.1	Starting the IP-GW16 Maintenance Utility	4
2	Administrator Functions	7
2.1	Main Menu for the Administrator	8
2.2	Programming	10
2.2.1	Network Parameters	10
2.2.2	H.323 Parameters	14
2.2.3	Voice Communication Parameters	18
2.2.4	VoIP Gateway/IP-PBX Interface Parameters	26
2.2.5	Hunt Pattern Parameters	28
2.2.6	Address Translation Table—GW Entry	34
2.2.7	Address Translation Table—DN2IP Entry	37
2.2.8	Initialisation	41
2.3	Maintenance	42
2.3.1	Status Control	42
2.3.2	Maintenance Settings	43
2.3.3	Diagnosis	46
2.3.4	Log Information	47
2.4	Data Management	48
2.4.1	Upload of Configuration Data	48
2.4.2	Download of Configuration Data	50
2.4.3	Upload of Address Translation Table	51
2.4.4	Download of Address Translation Table	53
2.5	Others	54
2.5.1	Reboot	54
2.5.2	Log Out	55
3	Installer Functions	57
3.1	Main Menu for the Installer	58
3.2	Maintenance	59
3.2.1	Status Control	59
3.2.2	Maintenance Settings	60
3.3	Data Management	62
3.3.1	Upload of Firmware Data	62
3.3.2	Handling of Firmware Page	65
3.4	Others	67
3.4.1	Reboot	67
3.4.2	Log Out	68
	Index	69

Section 1

IP-GW16 Maintenance Utility

Programming of the VoIP Gateway Card is carried out through a web programming utility called the IP-GW16 Maintenance Utility. This section provides the start-up procedure for the IP-GW16 Maintenance Utility.

1.1 Starting the IP-GW16 Maintenance Utility

The IP-GW16 Maintenance Utility is a web programming utility for the VoIP Gateway Card. There are 2 different log-in levels available: Administrator level and Installer level. These levels provide different programming options.

For full discussions of Administrator-level programming and Installer-level programming, refer to "2 Administrator Functions" and "3 Installer Functions", respectively.


System Requirements

- The IP-GW16 Maintenance Utility requires Microsoft® Internet Explorer 5.0 or above.


Trademarks

- Microsoft is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.
- All other trademarks identified herein are the property of their respective owners.
- Screen shots reprinted with permission from Microsoft Corporation.

1. Run Internet Explorer from the **Start** menu.
2. In the **Address** box of Internet Explorer, type **http://192.168.1.200**.
192.168.1.200 is the default IP address of the VoIP Gateway Card.



3. Press the ENTER key on the keyboard.
4. In the **Username** box, type the user name.
 - Default Administrator-level user name: **Administrator**
 - Default Installer-level user name: **Installer**
5. In the **Password** box, type the password.
 - Default Administrator-level password: **Administrator**
 - Default Installer-level password: **Installer**



6. Click **LOGIN**.
To clear your entry, click **CLEAR**.

Notes

- If another user is already logged in, you will be rejected.
- For readability of the text on the screen, it is recommended that you adjust the text size of Internet Explorer to below medium.
- If you finish a programming session without logging out from the card (e.g., quitting Internet Explorer, or returning to the log-in screen with the "Back" button of Internet Explorer), you cannot log in again for the period of time specified by the parameter **Programming Auto Disconnect Time** (default: 10 min).
For the log-out procedure and **Programming Auto Disconnect Time** setting, refer to "2.5.2 Log Out"/"3.4.2 Log Out" and "2.3.2 Maintenance Settings", respectively.

1.1 Starting the IP-GW16 Maintenance Utility

Section 2

Administrator Functions

This section provides operating instructions for the IP-GW16 Maintenance Utility when logged in as the Administrator.

2.1 Main Menu for the Administrator

The IP-GW16 Maintenance Utility provides the following menu to a user logged in as the Administrator.



Programming

Menu	Section Reference
1.1 Network Settings, General	2.2.1 Network Parameters
1.2 H.323 Detailed Settings	2.2.2 H.323 Parameters
1.3 Voice Communication Detailed Settings	2.2.3 Voice Communication Parameters
1.4 VoIP Gateway/IP-PBX Interface Settings	2.2.4 VoIP Gateway/IP-PBX Interface Parameters
1.5 Hunt Pattern (for Incoming Calls)	2.2.5 Hunt Pattern Parameters
1.6 DN2IP (Diald Number to IP Address Translation)	2.2.6 Address Translation Table—GW Entry 2.2.7 Address Translation Table—DN2IP Entry
1.7 Initialization	2.2.8 Initialisation

Maintenance

Menu	Section Reference
2.1 Change RUN/STOP status	2.3.1 Status Control
2.2 Maintenance Settings	2.3.2 Maintenance Settings
2.3 Diagnosis	2.3.3 Diagnosis
2.4 Log Information	2.3.4 Log Information

Data Management

Menu	Section Reference
3.1 Upload of Configuration data (PC → VoIP Gateway)	2.4.1 Upload of Configuration Data
3.2 Download of Configuration data (VoIP Gateway → PC)	2.4.2 Download of Configuration Data
3.3 Upload of DN2IP data (PC → VoIP Gateway)	2.4.3 Upload of Address Translation Table
3.4 Download of DN2IP data (VoIP Gateway → PC)	2.4.4 Download of Address Translation Table

Others

Menu	Section Reference
REBOOT	2.5.1 Reboot
LOGOUT	2.5.2 Log Out

2.2 Programming

2.2.1 Network Parameters

1. Click **1.1 Network Settings, General** in the main menu.

IP-GW16 Maintenance Utility - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Address http://192.168.1.200/ad_network.html

OK ALL CLEAR MENU LOGOUT

1. Programming
1.1 Network Settings, General

Current IP Address	192.168.1.200
Current Subnet Mask	255.255.255.0
Current Default Gateway	0.0.0.0

1.1.1 IP Address Settings

# IP Address	192.168.1.200
# Subnet Mask	255.255.255.0
# Default Gateway	0.0.0.0

1.1.2 DHCP Settings

# DHCP Server	<input type="radio"/> Use <input checked="" type="radio"/> Don't use
# DHCP Server Port No.	67
# DHCP Client Port No.	68
# DHCP Lease Time (min) 0-1440min (of interest to engineers only)	1440

1.1.3 HTTP Settings

# HTTP Port No.	80
-----------------	----

1.1.4 QSIG Connectionless Tunneling Settings

# QSIG Connectionless Tunneling Port No.	1718
------------------------------------------	------

1.1.5 Others

# LAN Disconnect Threshold Time (s)	5
-------------------------------------	---

indicates setting must be done in the STOP status, and must be followed by a REBOOT.

Current IP Address, Current Subnet Mask, and Current Default Gateway show the current IP address settings of the VoIP Gateway Card.

2. Assign each parameter referring to the descriptions below.

At any time during the session, you can:

- Click **ALL CLEAR** to return all parameters to their previous values.
- Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
- Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "2.5.2 Log Out").

3. Click **OK**.

You will see a confirmation screen.

Note

If your entry contains an invalid value, you will be prompted to correct your input. Enter correct values for the parameters shown in red and try again.

4. Confirm your entry and click **OK**.

To return to the previous screen, click **CANCEL**.

Parameter Descriptions

The parameters indicated with "#" must be changed while the card is in the "STOP" status (see "2.3.1 Status Control"). The changes must be followed by a reboot to become effective (see "2.5.1 Reboot").

IP Address Settings

Parameter & Description	Default	Value Range
# IP Address Specifies the IP address of the card. For more information, consult your network administrator.	192.168.1.200	The following addresses are invalid: <ul style="list-style-type: none"> • Class D addresses • Class E addresses • Loopback addresses • Addresses with host number all 0s or 1s
# Subnet Mask Specifies the subnet mask address of the card. For more information, consult your network administrator.	255.255.255.0	Any address is valid.
# Default Gateway Specifies the default gateway IP address of the card. For more information, consult your network administrator.	0.0.0.0	Same as the parameter IP Address , except that the address 0.0.0.0. is allowed.

DHCP Settings

Parameter & Description	Default	Value Range
# DHCP Server Specifies the use of a DHCP server. For details, refer to "Detailed Explanations".	Don't use	Use, Don't use
# DHCP Server Port No. Specifies the port number for DHCP communications by the DHCP server. Generally, there is no need to change the default value.	67	1 to 65535
# DHCP Client Port No. Specifies the port number for DHCP communications by the card (the DHCP client). Generally, there is no need to change the default value.	68	1 to 65535
# DHCP Lease Time (min) 1-1440min This parameter is provided for engineer use only.	1440	0 (disable), 1 to 1440

HTTP Settings

Parameter & Description	Default	Value Range
# HTTP Port No. Specifies the port number for HTTP communications by the card. Generally, there is no need to change the default value.	80	1 to 65535

QSIG Connectionless Tunneling Settings

Parameter & Description	Default	Value Range
# QSIG Connectionless Tunneling Port No. Specifies the port number for connectionless tunnelling between cards at different locations in a QSIG network. Generally, there is no need to change the default value. Notes <ul style="list-style-type: none"> Connectionless tunnelling enables the PBXs on a QSIG network to use enhanced networking features. (For more information about these features, refer to the relevant sections of the Hybrid IP-PBX documentation.) If you are using a gatekeeper, and "Routed" is specified for the parameter Call Signaling Model (see "2.2.2 H.323 Parameters"), connectionless tunnelling is not possible. In this case, the PBX cannot use the enhanced networking features. 	1718	1 to 65535

Others

Parameter & Description	Default	Value Range
# LAN Disconnect Threshold Time (s) Specifies the time (in seconds) until disconnection from the LAN is recognised. For example, even if a LAN cable is disconnected during a call, reconnecting the cable within this time period maintains the call.	5	1 to 10

Detailed Explanations

DHCP Server

When using the DHCP feature, the IP address settings of the card (IP address, subnet mask, and default gateway) will be assigned by a DHCP server.

However, keep in mind that the maintenance of the card is performed through a web browser from a PC; hence you must know the IP address of the card. Therefore, it is necessary to set up the DHCP

server to assign a static IP address to the card from a pool of IP addresses that is defined in advance. For more information about DHCP server settings, consult your network administrator.

In addition, it is also necessary to specify the values for the parameters under **IP Address Settings** as they will be assigned by the DHCP server.

2.2.2 H.323 Parameters

1. Click **1.2 H.323 Detailed Settings** in the main menu.

The screenshot shows the 'IP-GW16 Maintenance Utility - Microsoft Internet Explorer' window. The address bar shows 'http://192.168.1.200/ad_h323.html'. The interface includes buttons for 'OK', 'ALL CLEAR', 'MENU', and 'LOGOUT'. The settings are organized into sections:

- 1. Programming**
 - 1.2 H.323 Detailed Settings**
 - 1.2.1 Port No. Settings**

# H.225 Port No.	1720
# H.245 Port No.	1721
# RAS Port No.	1719
# RTP/RTCP Port No.	5004
 - 1.2.2 Voice CODEC Settings**

* Voice CODEC Priority	1st	G.729A
	2nd	None
	3rd	None
	4th	None
 - 1.2.3 Gatekeeper Settings**

# Gatekeeper	<input type="radio"/> Use <input checked="" type="radio"/> Don't use
* Primary Gatekeeper IP Address	192.168.1.3
* Primary Gatekeeper Port No.	1719
* Secondary Gatekeeper IP Address	192.168.1.4
* Secondary Gatekeeper Port No.	1719
* Gatekeeper Connection Checking Interval (min) 0-1440min	0
* Call Signaling Model	<input checked="" type="radio"/> Direct <input type="radio"/> Routed (via Gatekeeper)
 - 1.2.4 Others**

# Fast Connect	<input checked="" type="radio"/> Use <input type="radio"/> Don't use
----------------	----------------------------------------------------------------------

Footnote: # indicates setting must be done in the STOP status, and must be followed by a REBOOT.
 * indicates setting must be done in the STOP status, and is not followed by a REBOOT.

2. Assign each parameter referring to the descriptions below.
 At any time during the session, you can:
 - Click **ALL CLEAR** to return all parameters to their previous values.
 - Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
 - Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "2.5.2 Log Out").

3. Click **OK**.

You will see a confirmation screen.

Note

If your entry contains an invalid value, you will be prompted to correct your input. Enter correct values for the parameters shown in red and try again.

4. Confirm your entry and click **OK**.

To return to the previous screen, click **CANCEL**.

Parameter Descriptions

The parameters indicated with "#" must be changed while the VoIP Gateway Card is in the "STOP" status (see "2.3.1 Status Control"). The changes must be followed by a reboot to become effective (see "2.5.1 Reboot").

The parameters indicated with "*" must be changed while the card is in the "STOP" status (see "2.3.1 Status Control"). The changes do not have to be followed by a reboot to become effective.

Port No. Settings

Parameter & Description	Default	Value Range
# H.225 Port No. Specifies the port number for the H.225 protocol (call control) in an H.323 protocol suite. Generally, there is no need to change the default value.	1720	1 to 65535
# H.245 Port No. Specifies the port number for the H.245 protocol (negotiation of channel usage and capabilities) in an H.323 protocol suite. 32 consecutive ports, starting with the specified port, will be used (by default, 1721 to 1752). Generally, there is no need to change the default value.	1721	1 to 65504
# RAS Port No. Specifies the port number for the H.225 protocol (RAS) in an H.323 protocol suite. Generally, there is no need to change the default value.	1719	1 to 65535
# RTP/RTCP Port No. Specifies the port number for RTP/RTCP. 64 consecutive ports, starting with the specified port, will be used (by default, 5004 to 5067). Generally, there is no need to change the default value.	5004	1 to 65472

Voice CODEC Settings

Parameter & Description	Default	Value Range
<p>* Voice CODEC Priority 1st–4th</p> <p>Specifies the type of CODEC for voice communications. Choose the appropriate CODEC for the network environment (e.g., bandwidth, CODEC conditions of the remote terminal). When using multiple CODECs, set them in an appropriate priority order.</p> <p>Prior to establishing a call, a negotiation takes place over the network and the CODEC to be used will be decided depending on the setting of this parameter.</p> <p>For details about relations between bandwidth and CODEC, refer to "Detailed Explanations" in "2.2.3 Voice Communication Parameters".</p> <p>Note</p> <p>When the Fast Connect feature (see under "Others" below) is disabled, the communicating cards must have the same first priority CODEC set.</p>	<p>1st: G.729A 2nd: No default 3rd: No default 4th: No default</p>	<p>G.723.1, G.729A, G.711Mu, G.711A</p>

Gatekeeper Settings

Parameter & Description	Default	Value Range
<p># Gatekeeper</p> <p>Specifies the use of a gatekeeper. For details, refer to "Detailed Explanations".</p>	Don't use	Use, Don't use
<p>* Primary Gatekeeper IP Address</p> <p>Specifies the IP address of the primary gatekeeper.</p>	192.168.1.3	<p>The following addresses are invalid:</p> <ul style="list-style-type: none"> • Class D addresses • Class E addresses • Loopback addresses
<p>* Primary Gatekeeper Port No.</p> <p>Specifies the port number of the primary gatekeeper.</p>	1719	1 to 65535
<p>* Secondary Gatekeeper IP Address</p> <p>Specifies the IP address of the secondary gatekeeper. Set this parameter when setting up a secondary gatekeeper as a redundant backup system.</p>	192.168.1.4	<p>The following addresses are invalid:</p> <ul style="list-style-type: none"> • Class D addresses • Class E addresses • Loopback addresses
<p>* Secondary Gatekeeper Port No.</p> <p>Specifies the port number of the secondary gatekeeper. Set this parameter when setting up a secondary gatekeeper as a redundant backup system.</p>	1719	1 to 65535

Parameter & Description	Default	Value Range
* Gatekeeper Connection Checking Interval (min) 0-1440min Specifies the time (in minutes) between periodic checks of connection to the gatekeeper. When the primary gatekeeper fails, these checks can detect the failure. In this case, the connection automatically switches to the secondary gatekeeper if it is available, so that the network remains functional.	0	0 (disable), 1 to 1440
* Call Signaling Model Specifies whether to carry out a call control (H.225) process directly between the cards or through a gatekeeper. Direct call control is typically preferred because it involves less network load.	Direct	Direct, Routed (via Gatekeeper)

Others

Parameter & Description	Default	Value Range
# Fast Connect Specifies the use of the Fast Connect feature. Using Fast Connect simplifies the communication process so that calls can be established quickly. Generally, there is no need to change the default value.	Use	Use, Don't use

Detailed Explanations

Gatekeeper

The following are the general functions of a gatekeeper:

- Dialed number-to-IP address translation
- Authentication
- Bandwidth control

It is possible to employ a VoIP network without the use of a gatekeeper, because the card is equipped with internal address translation capabilities. However, should the network contain dozens of cards, maintenance of address translation tables in individual cards can become a strain.

A gatekeeper is useful in this case, because with the gatekeeper it is possible to consolidate the maintenance. (However, you still need to programme each card on the network with its own address translation information. For details, refer to "2.2.6 Address Translation Table—GW Entry" and "2.2.7 Address Translation Table—DN2IP Entry".) For more information about gatekeeper functions, consult the documentation of the gatekeeper.

When using a gatekeeper, make sure to choose a compatible model. For more information about gatekeeper compatibility with the card, consult a certified dealer.

2.2.3 Voice Communication Parameters

1. Click **1.3 Voice Communication Detailed Settings** in the main menu.

IP-GW16 Maintenance Utility - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Address http://192.168.1.200/ad_sound.html

OK ALL CLEAR MENU LOGOUT

1. Programming

1.3 Voice Communication Detailed Settings

1.3.1 QoS Field Settings

<input checked="" type="radio"/> ToS	Priority 0
<input checked="" type="radio"/> Normal	<input type="radio"/> Monetary Cost
<input type="radio"/> DSCP	<input type="radio"/> Reliability
<input type="radio"/> HEX	<input type="radio"/> Throughput
	<input type="radio"/> Delay

1.3.2 Jitter buffer Settings (G.711/G.729A/G.723.1 for Voice)

Jitter Buffer Minimum (ms)	20
Jitter Buffer Maximum (ms)	500
Jitter Buffer Default (ms)	20
Jitter Buffer Recovery Start (ms)	20
Jitter Buffer Recovery Period (s)	10

1.3.3 Jitter buffer Settings (G.711 for Fax)

Jitter Buffer Minimum (ms)	50
Jitter Buffer Maximum (ms)	500

1.3.4 CODEC Frame Settings

G.723.1 Packet Sending Interval (ms)	30
G.729A Packet Sending Interval (ms)	20
G.711 Packet Sending Interval (ms)	20

1.3.5 Echo Canceller Settings

Echo Canceller	<input checked="" type="radio"/> 48ms
	<input type="radio"/> 128ms
	<input type="radio"/> Don't use

1.3.6 Gain Level Settings

Gain Level PCM -> LAN (dB)	0
Gain Level LAN -> PCM (dB)	0

1.3.7 Voice Activity Detection(VAD) Settings

G.723.1 VAD	<input checked="" type="radio"/> Use
	<input type="radio"/> Don't use
G.729A VAD	<input type="radio"/> Use
	<input checked="" type="radio"/> Don't use
G.711 VAD	<input type="radio"/> Use
	<input checked="" type="radio"/> Don't use

1.3.8 Others

G.723.1 Rate	<input type="radio"/> 5.3Kbps
	<input checked="" type="radio"/> 6.3Kbps
DTMF Detection	<input checked="" type="radio"/> Use
	<input type="radio"/> Don't use
FAX Signal Detection	<input type="radio"/> Use
	<input checked="" type="radio"/> Don't use
DTMF Detection Level (dB) -46-0dB	-20

2. Assign each parameter referring to the descriptions below.
At any time during the session, you can:
 - Click **ALL CLEAR** to return all parameters to their previous values.
 - Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
 - Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "2.5.2 Log Out").
3. Click **OK**.

You will see a confirmation screen.

Note

If your entry contains an invalid value, you will be prompted to correct your input. Enter correct values for the parameters shown in red and try again.

4. Confirm your entry and click **OK**.

To return to the previous screen, click **CANCEL**.

Parameter Descriptions

QoS Field Settings

The parameters below are used to set the ToS (Type of Service) field in the header of IP packets to control QoS of VoIP communications.

For more information about QoS, refer to "A1.4 QoS (Quality of Service)" of the VoIP Gateway Card Getting Started. For the actual setting values, consult your network administrator.

Parameter & Description	Default	Value Range
ToS Specifies the value in the ToS field by a generic term. For details, refer to "Detailed Explanations".	Priority: 0	0 to 7
	Normal	Normal, Monetary Cost, Reliability, Throughput, Delay
DSCP Specifies the value in the ToS field by a DSCP for DiffServ.	No default	0 to 63
HEX Specifies the value in the ToS field by a hexadecimal number.	No default	00 to FF

Jitter Buffer Settings

When voice signals are packetised and transmitted, individual packets can take different paths through the network and arrive at the destination at varied timings. This is referred to as "jitter", and it can cause degradation in speech quality. To compensate for jitter problems, the "jitter buffer" accumulates the packets temporarily for processing.

The parameters below are used to adjust the size of the jitter buffer. However, in general, there is no need to change the default values.

Jitter buffer Settings (G.711/G.729A/G.723.1 for Voice)

Parameter	Default	Value Range
Jitter Buffer Minimum (ms)	20	10 × n (n = 2–10)
Jitter Buffer Maximum (ms)	500	10 × n (n = 2–50)
Jitter Buffer Default (ms)	20	10 × n (n = 2–10)
Jitter Buffer Recovery Start (ms)	200	10 × n (n = 2–10)
Jitter Buffer Recovery Period (s)	10	1 to 20

Jitter buffer Settings (G.711 for Fax)

Parameter	Default	Value Range
Jitter Buffer Minimum (ms)	50	10 × n (n = 4–10)
Jitter Buffer Maximum (ms)	500	10 × n (n = 4–50)

CODEC Frame Settings

The parameters below are used to set the interval between packet transmissions for each type of CODEC. It is recommended that all VoIP Gateway Cards in a VoIP network have the same settings for these parameters. For details, refer to "Detailed Explanations".

Parameter	Default	Value Range
G.723.1 Packet Sending Interval (ms)	30	30, 60, 90
G.729A Packet Sending Interval (ms)	20	20, 30, 40, 60
G.711 Packet Sending Interval (ms)	20	20, 30, 40, 60

Echo Canceller Settings

Parameter & Description	Default	Value Range
<p>Echo Canceller</p> <p>Specifies the length of the echo canceller (in milliseconds) when using the echo cancellation feature (G.168), or disables the feature.</p> <p>Echo is the audible duplication of a caller's voice on the return path; when echo exists, the caller hears his or her own voice after some delay. The echo canceller eliminates this echo.</p> <p>Generally, the default length of 48 ms will suffice. However, if an echo is still heard, it is recommended that you set the length to 128 ms.</p> <p>Note</p> <p>There are various factors that may cause an echo. In some cases, this feature does not eliminate the echo entirely.</p>	48	48, 128, Don't use

Gain Level Settings

The parameters below are used to adjust the gain level. However, in general, there is no need to change the default values.

Parameter & Description	Default	Value Range
Gain Level PCM → LAN (dB) Specifies the gain level (in decibels) output from the PBX, through the card, to the LAN.	0	-14 to 6
Gain Level LAN → PCM (dB) Specifies the gain level (in decibels) output from the LAN, through the card, to the PBX.	0	-14 to 6

Voice Activity Detection (VAD) Settings

Parameter & Description	Default	Value Range
G.723.1/G.729A/G.711 VAD Specifies the use of the VAD feature for each available CODEC (G.723.1, G.729A, and G.711). The VAD conserves bandwidth by detecting silent periods during a call and suppressing the packets of silence from being sent to the network. Notes <ul style="list-style-type: none"> To use the VAD feature for a certain CODEC, be sure to enable it for that CODEC on both the local and remote cards. To use the VAD feature between the KX-TDA0490 and KX-TDA3480/KX-TDA0484, you must enable it for the G.723.1 CODEC. Otherwise, the VAD feature cannot be used between these cards (although calls can be made and received as normal). 	Use	Use, Don't use

Others

Parameter & Description	Default	Value Range
G.723.1 Rate Specifies the rate of the G.723.1 CODEC.	6.3Kbps	5.3Kbps, 6.3Kbps
DTMF Detection Specifies the use of the DTMF detection feature. DTMF detection enables end-to-end DTMF relay over the network. For details, refer to "Detailed Explanations".	Use	Use, Don't use


Parameter & Description	Default	Value Range
FAX Signal Detection Specifies the use of the fax signal detection feature. Fax signal detection enables end-to-end fax signal relay over the network. For details, refer to "Detailed Explanations".	Don't use	Use, Don't use
DTMF Detection Level (dB) -46-0dB Specifies the level (in decibels) of DTMF detection. Generally, there is no need to change the default value.	-20	-46 to 0



Detailed Explanations

QoS Field Settings

The following diagrams show the bit values of the ToS field in the IP header in relation to the setting values for the parameters under **QoS Field Settings**:

ToS



DSCP**HEX****CODEC Frame Settings**

The amount of required bandwidth depends on the type of CODEC and the selected packet sending interval. The tables below show the amount of bandwidth required for one VoIP channel in each case:

Required Bandwidth for Voice Communication via LAN

CODEC	Packet Sending Interval				
	20 ms	30 ms	40 ms	60 ms	90 ms
G.711	87.2 kbps	79.5 kbps	75.6 kbps	71.7 kbps	—
G.729A	31.2 kbps	23.5 kbps	19.6 kbps	15.7 kbps	—
G.723.1 5.3 kbps	—	20.8 kbps	—	13.1 kbps	10.5 kbps
G.723.1 6.3 kbps	—	21.9 kbps	—	14.1 kbps	11.6 kbps

Required Bandwidth for Voice Communication via WAN (PPP: Point-to-Point Protocol)

CODEC	Packet Sending Interval				
	20 ms	30 ms	40 ms	60 ms	90 ms
G.711	84 kbps	77.3 kbps	74 kbps	70.7 kbps	—
G.729A	28 kbps	21 kbps	18 kbps	14.7 kbps	—
G.723.1 5.3 kbps	—	18.7 kbps	—	12 kbps	9.8 kbps
G.723.1 6.3 kbps	—	19.7 kbps	—	13.1 kbps	10.8 kbps

When assessing your bandwidth requirements, keep in mind that the longer the packet sending interval, the smaller the amount of required bandwidth, and vice versa.

However, also consider that the shorter the packet sending interval, the clearer the expected speech quality, because delays in packet transmissions will be small. When the packet sending interval is long, delays are more likely to occur, resulting in overall degradation in speech quality with more pauses and loss in voice communications.

Therefore, it is recommended that you select the shortest packet sending interval that network bandwidth can accommodate.

DTMF Detection

A VoIP network does not guarantee accurate end-to-end transmission of DTMF signals because the DTMF signals are coded/decoded during VoIP communications, in the same way as voice signals. In addition, packets can get lost during transmission.

To compensate for this problem, it is possible to enable DTMF detection for the VoIP Gateway Card to carry out accurate end-to-end DTMF relay over the network. Upon detecting DTMF signals from the PBX, the card encodes the signals and then sends them to the destination, instead of as voice signals. Then at the destination, the card regenerates the DTMF signals from the received encoded signals, and then sends them to the PBX.

Note that when this feature is enabled, the sending of packets is delayed by approximately 30 ms. Therefore, it is recommended that you disable this feature unless DTMF detection is necessary.

FAX Signal Detection

When sending fax signals using a CODEC other than G.711, the signals cannot be received accurately at the destination because they are coded/decoded over the VoIP network, in the same way as voice signals.

To compensate for this problem, it is possible to enable fax detection for the card. Upon detecting fax signals (CED tones) from the PBX, the card automatically switches the CODEC to G.711 to communicate with the card at the destination. With the G.711 CODEC, it is possible to assure error-free fax communications to a certain extent.

To further assure fax communications, it is strongly recommended that the communicating fax machines be equipped with the ECM (Error Correction Model) feature, an automatic error correction feature. When, for example, the receiving fax machine detects errors in transmission, it can have the sending fax machine resend the relevant data.

When using the fax detection feature, the communicating cards must share the same value (either "G.711Mu" or "G.711A") for the parameter **Voice CODEC Priority** (see "Voice CODEC Settings" in "2.2.2 H.323 Parameters").

Notes

- To carry out fax communications between the KX-TDA0490 and KX-TDA3480/KX-TDA0484 VoIP Gateway Cards, it is necessary to disable the **"FAX High Reliable Method"** for the KX-

TDA3480/KX-TDA0484 card. (For more information about this feature, refer to the KX-TDA3480/KX-TDA0484 Programming Guide.)

- Fax communications cannot take place between the KX-TDA0490 and KX-TDA0480 VoIP Gateway Cards.
- Fax communications in the Super G3 mode are not guaranteed.

2.2.4 VoIP Gateway/IP-PBX Interface Parameters

1. Click **1.4 VoIP Gateway/IP-PBX Interface Settings** in the main menu.

IP-GW16 Maintenance Utility - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Address http://192.168.1.200/ad_line.html

OK ALL CLEAR MENU LOGOUT

1. Programming
1.4 VoIP Gateway/IP-PBX Interface Settings

1.4.1 Dialing Settings

* First Digit Time (s) 5-30s	20
* Inter-Digit Time (s) 1-10s	5
* Digit End Code	#

1.4.2 Others

Network CODEC of IP-PBX (of interest to engineers only) ☐ G711 Mu-Law ☒ G711 A-Law

* indicates setting must be done in the STOP status, and is not followed by a REBOOT.

2. Assign each parameter referring to the descriptions below.
At any time during the session, you can:
 - Click **ALL CLEAR** to return all parameters to their previous values.
 - Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
 - Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "2.5.2 Log Out").

3. Click **OK**.

You will see a confirmation screen.

Note

If your entry contains an invalid value, you will be prompted to correct your input. Enter correct values for the parameters shown in red and try again.

4. Confirm your entry and click **OK**.

To return to the previous screen, click **CANCEL**.

Parameter Descriptions

The parameters indicated with "*" must be changed while the VoIP Gateway Card is in the "STOP" status (see "2.3.1 Status Control"). The changes do not have to be followed by a reboot to become effective.

Dialing Settings

Parameter & Description	Default	Value Range
* First Digit Time (s) 5-30s Specifies the length of time (in seconds) within which the first digit of a dial number must be dialled after seizing a VoIP gateway trunk. Generally, there is no need to change the default value.	20	5 to 30
* Inter-Digit Time (s) 1-10s Specifies the length of time (in seconds) within which subsequent digits of a dial number must be dialled. Generally, there is no need to change the default value.	5	1 to 10

Parameter & Description	Default	Value Range
* Digit End Code Specifies the delimiter code to be used to signal the end of a dial number. Generally, there is no need to change the default value.	#	0 to 9, #, *

Others

Parameter & Description	Default	Value Range
Network CODEC of IP-PBX The value of this parameter is set automatically as appropriate to the setting of the PBX. There is no need to change the value.	Not applicable	G.711 Mu-Law, G.711 A-Law

2.2.5 Hunt Pattern Parameters

1. Click **1.5 Hunt Pattern (for Incoming Calls)** in the main menu.

IP-GW16 Maintenance Utility - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Address http://192.168.1.200/ad_hunt_pattern.html

OK ALL CLEAR MENU LOGOUT

1. Programming
1.5 Hunt Pattern (for Incoming Calls)

1.5.1 Hunt Group

Port1	Hunt group 1
Port2	Hunt group 1
Port3	Hunt group 1
Port4	Hunt group 1
* Port5	Hunt group 1
Port6	Hunt group 1
Port7	Hunt group 1
Port8	Hunt group 1

1.5.2 Hunt Pattern Entry

Hunt Pattern No. (1-16)	
Receive Leading Number	
Hunt Group (Priority1)	1
Hunt Group (Priority2)	-
* Hunt Group (Priority3)	-
Hunt Group (Priority4)	-
Hunt Group (Priority5)	-
Hunt Group (Priority6)	-
Hunt Group (Priority7)	-
Hunt Group (Priority8)	-

* indicates setting must be done in the STOP status, and is not followed by a REBOOT.

ENTRY

Sort Option

Hunt Pattern No. Ascending Order

SORT

Hunt Pattern No.	Receive Leading Number	Hunt Group	DELETE
------------------	------------------------	------------	--------

2. Assign each parameter referring to the descriptions below.

At any time during the session, you can:

- Click **ALL CLEAR** to return all parameters to their previous values.
- Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
- Sort the hunt patterns in the table at the bottom of the screen:
 - a. Click the desired sort key and sort order from the **Sort Option** lists.
 - b. Click **SORT**.
- Delete the desired hunt pattern from the table at the bottom of the screen:
 - a. Select the appropriate check box for the hunt pattern you want to delete.
 - b. Click **DELETE**.
- Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "2.5.2 Log Out").

3. Click **ENTRY**.
A maximum of 16 hunt patterns can be created.
4. Click **OK**.
You will see a confirmation screen.

Note

If your entry contains an invalid value, you will be prompted to correct your input. Enter correct values for the parameters shown in red and try again.

5. Confirm your entry and click **OK**.
To return to the previous screen, click **CANCEL**.

Parameter Descriptions

The parameters indicated with "*" must be changed while the VoIP Gateway Card is in the "STOP" status (see "2.3.1 Status Control"). The changes do not have to be followed by a reboot to become effective.

Hunt Group

Parameter & Description	Default	Value Range
* Port1–8 Assigns a hunt group to a VoIP gateway port. For details, refer to "Detailed Explanations".	Hunt group 1	Hunt group 1 to 8

Hunt Pattern Entry


The parameters below are used to create hunt patterns.
For details, refer to "Detailed Explanations".

Parameter & Description	Default	Value Range
* Hunt Pattern No. Specifies the number for the hunt pattern to be created. When changing the current settings of an existing hunt pattern, first delete the hunt pattern and then re-create with new values.	No default	1 to 16
* Receive Leading Number Specifies the leading digits in received numbers by which to determine the hunt group to direct incoming calls. For example, to direct incoming calls with numbers starting with "9", specify the number "9" in this parameter. Likewise, to direct incoming calls with numbers starting with "1", specify the number "1". However, if you want to direct incoming calls with numbers starting with "950" and "951" to separate hunt groups, it is necessary to make 2 hunt patterns with respective numbers, "950" and "951".	No default	Max. 30 digits

Parameter & Description	Default	Value Range
* Hunt Group (Priority1) Specifies the hunt group to which incoming calls are directed first.	1	1 to 8
* Hunt Group (Priority2)–(Priority8) Specifies the hunt group to which incoming calls are directed when the hunt group specified in the previous priority level is busy.	-	1 to 8, - (disable)

Detailed Explanations

The card and the PBX are connected with 8 VoIP gateway ports, each of which has 2 communication channels, in much the same way as an ISDN BRI port.



Hunt pattern programming determines the VoIP gateway ports through which to route incoming calls, depending on the received numbers. The following examples provide 2 different methods of hunt pattern programming.

Example 1

The following configuration is used to allocate 8 VoIP gateway ports (16 channels) to route incoming calls to both extension groups A and B.


When there are 16 incoming calls to extension group A in this configuration, no call can be routed to extension group B.

Hunt Group

Port1	Hunt group 1
Port2	Hunt group 1
:	:
Port8	Hunt group 1

Hunt Pattern Entry

Hunt Pattern No.	1
Receive Leading Number	9
Hunt Group (Priority1)	1
Hunt Group (Priority2)	-
:	:
Hunt Group (Priority8)	-



Example 2

The following configuration is used to divide 8 VoIP gateway ports (16 channels) into 2 groups of 4, and then allocate each group to individual extension groups. Specifically, with this configuration, calls to extension group A are routed through the first group of ports (consisting of ports 1 to 4). Likewise, calls to extension group B are routed through the second group of ports (consisting of ports 5 to 8). When all 8 channels in the first group of ports are being used, this configuration rejects the 9th call to extension group A. However, the other 8 channels in the second group of ports remain available to route calls to extension group B.

Hunt Group


Port1	Hunt group 1
:	:
Port4	Hunt group 1
Port5	Hunt group 2
:	:
Port8	Hunt group 2

Hunt Pattern Entry—1

Hunt Pattern No.	1
Receive Leading Number	9501
Hunt Group (Priority1)	1
Hunt Group (Priority2)	-
:	:
Hunt Group (Priority8)	-

Hunt Pattern Entry—2

Hunt Pattern No.	2
Receive Leading Number	9502
Hunt Group (Priority1)	2
Hunt Group (Priority2)	-
:	:
Hunt Group (Priority8)	-



It is possible to programme the PBX to allocate separate groups of VoIP gateway ports to individual extension groups A and B for making outgoing calls. With this programming, each extension group, A and B, can have a group of ports for its exclusive use.

For example:


- The VoIP gateway ports that extension group A uses to make outgoing calls: ports 1 to 4
- The VoIP gateway ports that extension group B uses to make outgoing calls: ports 5 to 8

Note

The example above details the configuration to route incoming calls to 2 separate hunt groups, each of which is associated with an individual extension group. However, note that various other types of configurations are possible. For example, it is possible to route calls to 8 separate hunt groups, so that you can distribute the calls to 8 different extension groups.

2.2.6 Address Translation Table—GW Entry

1. Click **1.6 DN2IP (Dialed Number to IP Address Translation)** in the main menu.



2. Click **1.6.1 GW Entry**.

GW No.	Comment	IP Address	Group No.	DELETE
--------	---------	------------	-----------	--------

3. Assign each parameter referring to the descriptions below.

At any time during the session, you can:

- Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
- Click **PREVIOUS** to return to the previous screen.
- Sort the gateway entries in the table at the bottom of the screen:
 - a. Click the desired sort key and sort order from the **Sort Option** lists.
 - b. Click **SORT**.
- Delete the desired gateway entry from the table at the bottom of the screen:
 - a. Select the appropriate check box for the gateway entry you want to delete.

Note

If the gateway entry is registered to a DN2IP entry (see "2.2.7 Address Translation Table—DN2IP Entry"), no check box will be shown for the gateway entry.

b. Click **DELETE**.

- Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "2.5.2 Log Out").

4. Click **ENTRY**.

A maximum of 512 gateway entries can be created.

5. Click **OK**.

You will see a confirmation screen.

Note

If your entry contains an invalid value, you will be prompted to correct your input. Enter correct values for the parameters shown in red and try again.

6. Confirm your entry and click **OK**.

To return to the previous screen, click **CANCEL**.

Parameter Descriptions

The parameters indicated with "*" must be changed while the VoIP Gateway Card is in the "STOP" status (see "2.3.1 Status Control"). The changes do not have to be followed by a reboot to become effective.

GW Entry

The parameters below are used to create gateway entries for both local and remote cards on the network, as a preliminary step to programming the address translation table (DN2IP).

For a programming example, refer to "3.2.5 Programming the Address Translation Table" of the VoIP Gateway Card Getting Started.

Note

If you are using a gatekeeper, create the gateway entry only for the local card.


Parameter & Description	Default	Value Range
* GW No. Specifies the number for the gateway entry to be created. When changing the current settings of an existing gateway entry, first delete the gateway entry and then re-create with new values.	0	0 to 511
* Comment Specifies the comment for the gateway entry.	No default	Max. 16 characters
* IP Address Specifies the IP address of the card.	No default	The following addresses are invalid: <ul style="list-style-type: none"> Class D addresses Class E addresses Loopback addresses

2.2 Programming

Parameter & Description	Default	Value Range
<p>* Group No.</p> <p>Specifies the number of the gateway group to which the gateway entry belongs.</p> <p>Grouping is useful when there is more than one card installed in a PBX, because it allows you to use the automatic route redirection feature. For details, refer to "Detailed Explanations" in the next section, "2.2.7 Address Translation Table—DN2IP Entry".</p>	0	0 (belong to no group), 1 to 256

2.2.7 Address Translation Table—DN2IP Entry

1. Click **1.6 DN2IP (Dialled Number to IP Address Translation)** in the main menu.



2. Click **1.6.2 DN2IP Entry**.

3. Assign each parameter referring to the descriptions below.

At any time during the session, you can:

- Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
- Click **PREVIOUS** to return to the previous screen.
- Sort the DN2IP entries in the table at the bottom of the screen:
 - a. Click the desired sort key and sort order from the **Sort Option** lists.
 - b. Click **SORT**.
- Delete the desired DN2IP entry from the table at the bottom of the screen:
 - a. Select the appropriate check box for the DN2IP entry you want to delete.
 - b. Click **DELETE**.
- Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "2.5.2 Log Out").

4. Click **ENTRY**.

A maximum of 512 DN2IP entries can be created.

5. Click **OK**.

You will see a confirmation screen.

Note

If your entry contains an invalid value, you will be prompted to correct your input. Enter correct values for the parameters shown in red and try again.

6. Confirm your entry and click **OK**.

To return to the previous screen, click **CANCEL**.

Parameter Descriptions

The parameters indicated with "*" must be changed while the VoIP Gateway Card is in the "STOP" status (see "2.3.1 Status Control"). The changes do not have to be followed by a reboot to become effective.

DN2IP Entry

The parameters below are used to create DN2IP entries based on the gateway entries created previously (see "2.2.6 Address Translation Table—GW Entry"). The DN2IP entries associate dialed numbers and IP address of the destination; therefore, a caller can reach the destination by dialling the number without knowing the destination IP address.

For a programming example, refer to "3.2.5 Programming the Address Translation Table" of the VoIP Gateway Card Getting Started.

Note

If you are using a gatekeeper, create the DN2IP entries only for the local card. In this case, you can create up to 4 DN2IP entries per card.

Note that if you are not using a gatekeeper, there is no maximum number of DN2IP entries.

Parameter & Description	Default	Value Range
<p>* Leading Number</p> <p>Specifies the leading digits in dialled numbers by which to associate calls with the appropriate destination.</p> <p>For example, to associate calls with dialled numbers "950-xxxx" and "951-xxxx" with separate destinations, it is necessary to make 2 DN2IP entries with respective numbers, "950" and "951".</p>	No default	Max. 30 digits
<p>* Remaining Number of Digits</p> <p>Specifies the number of digits to be dialled following the leading number to access the destination.</p> <p>For example, if the dialled numbers are either "950-xxxx" or "951-xxxx" and the numbers "950" and "951" are specified for the parameter Leading Number respectively, specify the number "4" in this parameter.</p>	0	0 to 29
<p>* GW No/Group No. Selection</p> <p>Specifies the type of destination when making calls: a gateway or a gateway group.</p>	GW	GW, Group

Parameter & Description	Default	Value Range
* GW No/Group No. Specifies the number of the destination gateway or gateway group.	GW No: 0, Group No.: 1	GW No: 0 to 511, Group No.: 1 to 256

Detailed Explanations


Automatic Route Redirection

When more than one card is installed in a PBX, you can assign them to a single gateway group. Grouping allows you to logically combine the channels of multiple cards in a PBX (there are 16 channels per card). This aids the effective use of channels in a PBX.

The following diagram and tables provide an example of this configuration.

Example of Configuration

In the diagram below, there are 2 cards (cards B and C) installed in PBX 2.



Example of Gateway Entry Programming

Through gateway entry programming, cards B and C are grouped into a single gateway group.

Parameter	Card A	Card B	Card C
GW No	0	1	2
Comment	IP-GW Card A	IP-GW Card B	IP-GW Card C
IP Address	192.168.1.1	192.168.1.2	192.168.1.3
Group No.	0	1	1

Example of DN2IP Entry Programming

When DN2IP entries are programmed as in the table below, calls through card A arrive at gateway group 1, which includes cards B and C.

Parameter	To Card A	To Gateway Group 1 (Cards B and C)
Leading Number	951	952

2.2 Programming

Parameter	To Card A	To Gateway Group 1 (Cards B and C)
Remaining Number of Digits	3	4
GW No/Group No. Selection	GW	Group
GW No/Group No.	0	1

The automatic route redirection feature activates in this configuration. If a call is made through card A to gateway group 1 when all 16 channels of card B are busy, card A automatically redirects the call to card C.


This is possible because by grouping, PBX 1 sees PBX 2 as having a combined set of 32 channels, not 2 separate sets of 16 channels.

Note

The automatic route redirection feature cannot be used in a network where a gatekeeper is used. For details about gatekeeper settings, refer to "Gatekeeper Settings" in "2.2.2 H.323 Parameters".


2.2.8 Initialisation

1. Click **1.7 Initialization** in the main menu.



2. Click **OK** to initialise all parameters to the default values.

To abort initialisation, click **CANCEL**. You will be taken back to the main menu (see "2.1 Main Menu for the Administrator").



Initialisation has to be followed by a reboot to make the default values effective for the parameters indicated with "#" (e.g., IP address of the VoIP Gateway Card). If not followed by a reboot, the current setting values will remain effective instead.

3. Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
4. Refer to "2.5.1 Reboot" and finish the reboot.

Note

If you have forgotten the IP address or log-in password of the VoIP Gateway Card, follow the procedure detailed in "C1 Initialising the VoIP Gateway Card" of the VoIP Gateway Card Getting Started to return all settings to the factory default.

2.3 Maintenance

2.3.1 Status Control

1. Click **2.1 Change RUN/STOP status** in the main menu.

Current RUN/STOP Status	RUN
Status after changing	<input type="radio"/> RUN <input checked="" type="radio"/> STOP
Forced Disconnect when executing STOP	<input type="checkbox"/> Yes

OK MENU LOGOUT

Current RUN/STOP Status shows the current status of the VoIP Gateway Card.

2. Click **RUN** or **STOP** for **Status after changing**.

If you want to forcibly change the status from "RUN" to "STOP" while there are ongoing calls, click the **Yes** check box for **Forced Disconnect when executing STOP**. This will allow you to place the card in the "STOP" status even when there are ongoing calls.

At any time during the session, you can:

- Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
- Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "2.5.2 Log Out").

3. Click **OK**.

You will see a confirmation screen.

4. Click **OK**.

You will see a result screen.

Note


If the operation is not successful, you will see an error screen. Click **OK** to return to the previous screen, and then try again.

5. Click **OK**.

You will be taken back to the **Change RUN/STOP status** screen.

2.3.2 Maintenance Settings

1. Click **2.2 Maintenance Settings** in the main menu.



2. Assign each parameter referring to the descriptions below.

At any time during the session, you can:

- Click **ALL CLEAR** to return all parameters to their previous values.
- Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
- Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "2.5.2 Log Out").

3. Click **OK**.

You will see a confirmation screen.

Note

If your entry contains an invalid value, you will be prompted to correct your input. Enter correct values for the parameters shown in red and try again.

4. Confirm your entry and click **OK**.

To return to the previous screen, click **CANCEL**.

Parameter Descriptions

The parameters indicated with "*" must be changed while the VoIP Gateway Card is in the "STOP" status (see "2.3.1 Status Control"). The changes do not have to be followed by a reboot to become effective.

Username/Password Settings

Parameter & Description	Default	Value Range
Username for Administrator Administrator-level log-in user name.	Administrator	Max. 16 characters

Parameter & Description	Default	Value Range
Password Administrator-level log-in password.	Administrator	Max. 16 characters
Password (Confirmation) Confirmation of the administrator-level log-in password.	No default	Max. 16 characters

Programming Auto Disconnect Time Settings

Parameter & Description	Default	Value Range
Programming Auto Disconnect Time (min) 1-30min Specifies the time (in minutes) until programming is automatically terminated. If the specified period of time passes with no programming input, programming will automatically be terminated. This prevents problems caused by continuation of log-in status in cases such as being unable to log out due to the sudden failure of a PC.	10	1 to 30

Periodic Diagnosis Time Interval Settings

Parameter & Description	Default	Value Range
* Periodic Diagnosis Time Interval (min) 0-1440min Specifies the time (in minutes) between periodic self-diagnoses to test operation as described in "2.3.3 Diagnosis". If failures are detected during the self-diagnosis, the card will alert the PBX.	60	0 (no periodic diagnosis), 1 to 1440

Version


Parameter & Description	Default	Value Range
IP-GW16 Program Version Indicates the version of the VoIP Gateway Card's main programme. The main programme controls the VoIP protocol.	Display only	
DSP Program Version Indicates the version of the VoIP Gateway Card's DSP programme. The DSP programme controls a DSP device, which controls speech and audio processing.		
DSP Device Version Indicates the version of the VoIP Gateway Card's DSP device. The DSP device is a processor that controls speech and audio processing.		

2.3.3 Diagnosis


This function is used to carry out the self-diagnostic programme manually.

If failures are detected, there is a potential for trouble with the operation of the VoIP Gateway Card.

1. Click **2.3 Diagnosis** in the main menu.



2. Click **DIAGNOSIS** to carry out the self-diagnostic programme.



3. Do one of the following:
 - Click **DIAGNOSIS** to carry out the self-diagnostic programme again.
 - Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
 - Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "2.5.2 Log Out").

2.3.4 Log Information

The function to collect log information is provided for engineer use only. However, in the case that a need should arise, this section provides the procedure for collecting the log information.

1. Click **2.4 Log Information** in the main menu.

The screenshot shows the 'IP-GW16 Maintenance Utility' web interface in Microsoft Internet Explorer. The address bar shows 'http://192.168.1.200/ad_log_option.html'. The page content includes a navigation menu with '2. Maintenance' and '2.4 Log Information (of interest to engineers only)'. Below the menu, there are configuration options for log collection:

- Sort by Time/Date:** Radio buttons for 'Ascending Order' and 'Descending Order' (selected).
- Log Target:** Checkboxes for 'Error Log' (checked), 'Call Log' (checked), and 'Protocol Log' (unchecked).
- Error Log Filter:** Checkboxes for 'Information' (checked), 'Minor Error' (checked), and 'Major Error' (checked).
- Protocol Log Filter:** Checkboxes for 'H.225.0' (unchecked), 'H.245' (unchecked), 'RAS' (unchecked), 'DPRAM' (unchecked), 'LAPD' (unchecked), 'QSIG' (unchecked), and 'Others' (unchecked).
- Number of Log items:** A dropdown menu set to '100'.
- Date Format:** Radio buttons for 'MM-DD-YYYY' (selected) and 'DD-MM-YYYY'.

At the bottom of the configuration section are three buttons: 'OK', 'MENU', and 'LOGOUT'.

2. Click **OK**.

Log information is displayed.

The screenshot shows the 'IP-GW16 Maintenance Utility' web interface in Microsoft Internet Explorer. The address bar shows 'http://192.168.1.200/ad_log_info.html'. The page content includes a navigation menu with '2. Maintenance' and '2.4 Log Information (of interest to engineers only)'. Below the menu, there is a table with the following headers: 'Date', 'Time', 'Type', and 'Explanation'. Below the table, there are two links: 'Download (All)' and 'Download (Displayed portion only)'. At the bottom of the page are five buttons: 'UPDATE', 'LOG SETTING', 'CLEAR', 'MENU', and 'LOGOUT'.

3. Click **Download (All)** to download the log information.

2.4 Data Management


It is strongly recommended that you download the configuration data and the address translation table (DN2IP) data from the VoIP Gateway Card for backup and archive purposes.

The following sections provide the procedures for downloading and uploading.

2.4.1 Upload of Configuration Data

Before uploading the data, place the card in the "STOP" status (see "2.3.1 Status Control").

1. Click **3.1 Upload of Configuration data (PC → VoIP Gateway)** in the main menu.




2. Click **Browse** and choose a file to upload.
At any time during the session, you can:
 - Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
 - Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "2.5.2 Log Out").
3. Click **UPLOAD (PC→VoIP Gateway)**.

The upload operation starts.

Notes


- If the upload operation is executed while the card is in the "RUN" status, you will see an error screen. Click **Change RUN/STOP status Screen** and place the card in the "STOP" status (see "2.3.1 Status Control"), and then upload the data again.
- If the operation is not successful for other reasons, you will see another error screen. Click **OK** to return to the previous screen, and then upload the data again.



4. Do one of the following:
- Click **REBOOT** to make the changes effective now.
You will see a confirmation screen. Refer to "2.5.1 Reboot" and finish the reboot.
 - Click **OK** to return to the previous screen without rebooting.
However, remember to reboot the card at the end of the programming session to make changes effective.

2.4.2 Download of Configuration Data

1. Click **3.2 Download of Configuration data (VoIP Gateway → PC)** in the main menu.



2. Click **DOWNLOAD**.

At any time during the session, you can:


- Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
- Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "2.5.2 Log Out").

3. Specify the file name and the folder in which to save the file.

2.4.3 Upload of Address Translation Table

Before uploading the data, place the card in the "STOP" status (see "2.3.1 Status Control").

1. Click **3.3 Upload of DN2IP data (PC → VoIP Gateway)** in the main menu.



2. Click **Browse** and choose a file to upload.

At any time during the session, you can:


- Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
- Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "2.5.2 Log Out").

3. Click **UPLOAD (PC→VoIP Gateway)**.

The upload operation starts.

Notes

- If the upload operation is executed while the card is in the "RUN" status, you will see an error screen. Click **Change RUN/STOP status Screen** and place the card in the "STOP" status (see "2.3.1 Status Control"), and then upload the data again.
- If the operation is not successful for other reasons, you will see another error screen. Click **OK** to return to the previous screen, and then upload the data again.



4. Do one of the following:


- Click **REBOOT** to make the changes effective now.
You will see a confirmation screen. Refer to "2.5.1 Reboot" and finish the reboot.
- Click **OK** to return to the previous screen without rebooting.

2.4 Data Management

However, remember to reboot the card at the end of the programming session to make changes effective.

2.4.4 Download of Address Translation Table

1. Click **3.4 Download of DN2IP data (VoIP Gateway → PC)** in the main menu.



2. Click **DOWNLOAD**.

At any time during the session, you can:


- Click **MENU** to return to the main menu (see "2.1 Main Menu for the Administrator").
- Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "2.5.2 Log Out").

3. Specify the file name and the folder in which to save the file.

2.5 Others


2.5.1 Reboot

1. Click **REBOOT** in the main menu.



2. Click **REBOOT**.

To return to the main menu, click **CANCEL** (see "2.1 Main Menu for the Administrator").




Note

If the reboot operation is not successful, you will see an error page.

3. To continue programming, click **LOGIN Screen** and log in again.
You will see the log-in screen (see "1.1 Starting the IP-GW16 Maintenance Utility").

2.5.2 Log Out

1. Click **LOGOUT** in the main menu.



2. Click **OK** to log out.


Section 3

Installer Functions

This section provides operating instructions for the IP-GW16 Maintenance Utility when logged in as the Installer.

3.1 Main Menu for the Installer

The IP-GW16 Maintenance Utility provides the following menu to a user logged in as the Installer.



Maintenance

Menu	Section Reference
1.1 Change RUN/STOP status	3.2.1 Status Control
1.2 Maintenance Settings	3.2.2 Maintenance Settings

Data Management

Menu	Section Reference
2.1 Upload of Firmware data (PC → VoIP Gateway)	3.3.1 Upload of Firmware Data
2.2 Handling of Firmware Page	3.3.2 Handling of Firmware Page

Others

Menu	Section Reference
REBOOT	3.4.1 Reboot
LOGOUT	3.4.2 Log Out

3.2 Maintenance

3.2.1 Status Control

1. Click **1.1 Change RUN/STOP status** in the main menu.

Current RUN/STOP Status shows the current status of the VoIP Gateway Card.

2. Click **RUN** or **STOP** for **Status after changing**.

If you want to forcibly change the status from "RUN" to "STOP" while there are ongoing calls, click the **Yes** check box for **Forced Disconnect when executing STOP**. This will allow you to place the card in the "STOP" status even when there are ongoing calls.

At any time during the session, you can:

- Click **MENU** to return to the main menu (see "3.1 Main Menu for the Installer").
- Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "3.4.2 Log Out").

3. Click **OK**.

You will see a confirmation screen.

4. Click **OK**.

You will see a result screen.

Note


If the operation is not successful, you will see an error screen. Click **OK** to return to the previous screen, and then try again.

5. Click **OK**.

You will be taken back to the **Change RUN/STOP status** screen.

3.2.2 Maintenance Settings

1. Click **1.2 Maintenance Settings** in the main menu.



2. Assign each parameter referring to the descriptions below.
At any time during the session, you can:
 - Click **ALL CLEAR** to return all parameters to their previous values.
 - Click **MENU** to return to the main menu (see "3.1 Main Menu for the Installer").
 - Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "3.4.2 Log Out").

3. Click **OK**.

You will see a confirmation screen.

Note

If your entry contains an invalid value, you will be prompted to correct your input. Enter correct values for the parameters shown in red and try again.

4. Confirm your entry and click **OK**.

To return to the previous screen, click **CANCEL**.

Parameter Descriptions

Username/Password Settings

Parameter & Description	Default	Value Range
Username for Installer Installer-level log-in user name.	Installer	Max. 16 characters
Password Installer-level log-in password.	Installer	Max. 16 characters
Password (Confirmation) Confirmation of the installer-level log-in password.	No default	Max. 16 characters

Version

Parameter & Description	Default	Value Range
IP-GW16 Program Version Indicates the version of the VoIP Gateway Card's main programme. The main programme controls the VoIP protocol.	Display only	
DSP Program Version Indicates the version of the VoIP Gateway Card's DSP programme. The DSP programme controls a DSP device, which controls speech and audio processing.		
DSP Device Version Indicates the version of the VoIP Gateway Card's DSP device. The DSP device is a processor that controls speech and audio processing.		

3.3 Data Management

The upload and update operations of the firmware data are closely related. First follow the procedure as described in "3.3.1 Upload of Firmware Data" to upload new firmware data to the VoIP Gateway Card, and then go on to "3.3.2 Handling of Firmware Page" to update the card with the newly uploaded firmware data.

3.3.1 Upload of Firmware Data

Before uploading the data, place the card in the "STOP" status (see "3.2.1 Status Control").

1. Click **2.1 Upload of Firmware data (PC → VoIP Gateway)** in the main menu.

The screenshot shows a web browser window titled "IP-GW16 Maintenance Utility - Microsoft Internet Explorer". The address bar shows "http://192.168.1.200/firm_down.html". The page content is as follows:

2. Data Management
2.1 Upload of Firmware data (PC -> VoIP Gateway)

Upload Operation (Make sure to complete **Step 4.**)

Step 1: Upload the firmware data to the temporary buffer.

Step 2: Copy the uploaded firmware data to Page-0 or Page-1.

Step 3: Start up with the uploaded firmware (REBOOT).

Step 4: **After the reboot, change the firmware status of the updated page from "NEW" to "Main Operation Mode".**

For details, refer to "Programming Guide - Data Management".

(Step-1) Upload to the temporary buffer.

Enter upload file name.

If you are sure, click UPLOAD.

2. Do the following to upload the firmware data to the temporary buffer in the VoIP Gateway Card:
 - a. Click **Browse** and choose a file to upload.
At any time during the session, you can:
 - Click **MENU** to return to the main menu (see "3.1 Main Menu for the Installer").
 - Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "3.4.2 Log Out").
 - b. Click **UPLOAD (PC→VoIP Gateway)**.
The upload operation starts.

Note

If the upload operation is executed while the card is in the "RUN" status, you will see an error screen. Click **Change RUN/STOP status Screen** and place the card in the "STOP" status (see "3.2.1 Status Control"), and then upload the data again.

2. Data Management
2.1 Upload of Firmware data (PC -> VoIP Gateway)

Upload of Firmware data has finished OK.

(Step-2) Copy the uploaded Firmware data in temporary buffer to Page-0 or Page-1

Select Page-0 or Page-1.

Firmware Status	Page-0: Main Operation Mode Page-1: OLD
Startup Page	Page-0
Select Page	<input type="radio"/> Page-0 <input checked="" type="radio"/> Page-1

If you are sure, click OK.
To cancel the copy, click BACK button on your browser.

OK

Firmware Status shows the current firmware status of page 0 and page 1, and **Startup Page** shows the current active page on startup. For details about these parameters, refer to "3.3.2 Handling of Firmware Page".

3. Do the following to update the desired page with the uploaded firmware data:
 - a. In **Select Page**, click the page whose current firmware status is not "Main Operation Mode".
 - b. Click **OK**.
You will see a confirmation screen.
 - c. Click **OK**.

2. Data Management
2.1 Upload of Firmware data (PC -> VoIP Gateway)

Copy of Firmware data has finished OK.

(Step-3) Startup with the uploaded Firmware data for confirmation.

Before you click REBOOT, please read the following instruction.
After the reboot, make sure to change the firmware status from "NEW" to "Main Operation Mode" in "2.2 Handling of Firmware Page".
NOTE: If you do not change the firmware status, the old firmware will be used automatically after the next reboot.
For details, refer to "Programming Guide - Data Management".

REBOOT CANCEL

4. Click **REBOOT** to start up the card with the updated page.
You will see a reboot confirmation screen.
5. Click **REBOOT** again.

Notice

Please note that rebooting the card does not finish the upload operation. The startup page will be updated only temporarily for confirmation purposes.

6. Click **Login Screen** to continue the upload operation.
The card has rebooted with the new firmware data temporarily so that you can confirm the result of the upload operation.
At this point, the firmware status of the updated page is "NEW". To complete the upload operation, you must proceed to the next step and change the status to "Main Operation Mode". (If you do not, the card will start up with the old firmware data after the next reboot.)
7. Switch the firmware status of the updated page from "NEW" to "Main Operation Mode", referring to "3.3.2 Handling of Firmware Page".

The following is an example of the screen where the updated page has been set to "Main Operation Mode". To set the updated page as the active page on startup, you must apply this setting.

IP-GW16 Maintenance Utility - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Address http://192.168.1.200/firm_state_chg.html

2. Data Management
2.2 Handling of Firmware Page

Please operate page-related functions.

	IP-GW16 Program Version	DSP Program Version	Firmware Status	Startup Page
Page-0	2.000	3.000.0	OLD	
Page-1	2.001	3.000.1	Main Operation Mode	x

Operation: ☐ Empty ☒ Main Operation Mode

Select Page: ☐ Page-0 ☒ Page-1

OK MENU LOGOUT

3.3.2 Handling of Firmware Page

1. Click **2.2 Handling of Firmware Page** in the main menu.

For details about the parameters on this screen, refer to the descriptions below.

2. In **Operation**, click **Main Operation Mode** to set the desired page as the active page on startup.

Note

Do not click **Empty**, as it is an option provided for engineer use only.

At any time during the session, you can:

- Click **MENU** to return to the main menu (see "3.1 Main Menu for the Installer").
- Click **LOGOUT** to log out from the IP-GW16 Maintenance Utility (see "3.4.2 Log Out").

3. In **Select Page**, click the page whose current firmware status is not "Main Operation Mode" to specify it as the target page of the operation.
4. Click **OK**.
You will see a confirmation screen.
5. Click **OK**.
You will see a result screen.
6. Click **OK**.
You will be taken back to the **Handling of Firmware Page** screen.

Parameter Descriptions


Parameter & Description	Default	Value Range
IP-GW16 Program Version Indicates the version of the VoIP Gateway Card's main programme in the firmware data of the corresponding page.	Display only	
DSP Program Version Indicates the version of the VoIP Gateway Card's DSP programme in the firmware data of the corresponding page.	Display only	

Parameter & Description	Default	Value Range
Firmware Status Indicates the current firmware status of the corresponding page. There are 3 kinds of status indications: <ul style="list-style-type: none"> • Main Operation Mode: Active firmware data on startup under normal operation. • OLD: Firmware data uploaded to the card before the firmware data in the "Main Operation Mode" status was uploaded. • NEW: Firmware data uploaded to the card after the firmware data in the "Main Operation Mode" status was uploaded. Note The status indications "OLD" and "NEW" are irrelevant to the version of the firmware data.	Display only	
Startup Page Indicates (with an "x" sign) the active page on startup. Generally, the startup page is the firmware data whose status is "Main Operation Mode". The exception is when the card undergoes a reboot after a firmware data upload operation; in this case, the card starts up with the page in the "NEW" status. This is for the purposes of confirming the result of the upload operation. If you reboot again, the card starts up with the page in the "Main Operation Mode" status. To set the updated page as the active page on startup, you must change its firmware status to "Main Operation Mode".	Display only	
Operation Specifies whether to set the page (selected with the parameter Select Page) as the active page on startup (" Main Operation Mode "), or delete the page (" Empty "). " Empty " is an option provided for engineer use only.	Not applicable	Empty, Main Operation Mode
Select Page Specifies the target page of the operation selected with the parameter Operation .	Not applicable	Page-0, Page-1

3.4 Others


3.4.1 Reboot

1. Click **REBOOT** in the main menu.



2. Click **REBOOT**.

To return to the main menu, click **CANCEL** (see "3.1 Main Menu for the Installer").




Note

If the reboot operation is not successful, you will see an error page.

3. To continue programming, click **LOGIN Screen** and log in again.
You will see the log-in screen (see "1.1 Starting the IP-GW16 Maintenance Utility").

3.4.2 Log Out

1. Click **LOGOUT** in the main menu.



2. Click **OK** to log out.

Index

A

Automatic Route Redirection 39

B

Bandwidth 23

C

Call Signaling Model 17
Change RUN/STOP status 42, 59
CODEC Frame Settings 20, 23

D

Default Gateway 11
DHCP Settings 11
Diagnosis 46
Dialing Settings 26
DiffServ 19
Digit End Code 27
DN2IP (Diald Number to IP Address Translation) 34, 37
DN2IP Entry 37, 38
Download of Address Translation Table 53
Download of Configuration Data 50
DSCP 19, 23
DSP Program Version 65
DTMF Detection 21, 24
DTMF Detection Level 22
DTMF Relay 21, 24

E

Echo Cancellor 20
ECM (Error Correction Model) 24
Empty 66

F

Fast Connect 17
FAX Signal Detection 22, 24
Firmware Status 66
First Digit Time 26

G

G.168 20
G.711A 16
G.711Mu 16
G.723.1 16
G.723.1 Rate 21
G.723.1/G.729A/G.711 VAD 21
G.729A 16
Gatekeeper Settings 16
GW Entry 34, 35

H

H.225 Port No. 15
H.245 Port No. 15
H.323 14
H.323 Detailed Settings 14
Handling of Firmware Page 65
HTTP Settings 12

Hunt Pattern (for Incoming Calls) 28

I

Initialisation 41
Inter-Digit Time 26
IP Address 11
IP Address Settings 11
IP Header 19, 22
IP-GW16 Program Version 65

J

Jitter Buffer Settings 19
Jitter buffer Settings (G.711 for Fax) 20
Jitter buffer Settings (G.711/G.729A/G.723.1 for Voice) 19

L

LAN 23
LAN Disconnect Threshold Time 12
Log Information 47
Log Out 55, 68

M

Main Menu for the Administrator 8
Main Menu for the Installer 58
Main Operation Mode 66
Maintenance Settings 43, 60

N

Network CODEC of IP-PBX 27
Network Settings, General 10

P

Packet Sending Interval 20, 23, 24
Periodic Diagnosis Time Interval Settings 44
Port No. Settings 15
PPP (Point-to-Point Protocol) 24
Programming Auto Disconnect Time Settings 44

Q

QoS Field Settings 19, 22
QSIG Connectionless Tunneling Settings 12

R

RAS Port No. 15
Reboot 54, 67
RTP/RTCP Port No. 15

S

Startup Page 66
Subnet Mask 11
Super G3 Mode 25

T

ToS 19, 22

U

Upload of Address Translation Table	51
Upload of Configuration Data	48
Upload of Firmware Data	62
Username/Password Settings	43, 60

V

VAD (Voice Activity Detection)	21
Version	45, 61
Voice CODEC Settings	16
Voice Communication Detailed Settings	18
VoIP Gateway/IP-PBX Interface Settings	26

Panasonic Communications Co., Ltd.

1-62, 4-chome, Minoshima, Hakata-ku, Fukuoka 812-8531, Japan

Copyright:

This material is copyrighted by Panasonic Communications Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic Communications Co., Ltd.

© 2004 Panasonic Communications Co., Ltd. All Rights Reserved.